## 30" Wood Burning Firepit with Scroll Design



MODEL # FT-022

AZPH-YAYI



#### ATTACH YOUR RECEIPT HERE

Serial Number \_\_\_\_

\_\_\_\_\_ Purchase Date \_\_\_\_\_



**Questions, problems, missing parts?** For small parts please call 1-888-775-1330 for assistance, 8 a.m. - 4 p.m., MST, Monday - Friday. For damaged product, you may have to return to the retailer.

# OWNER'S MANUAL

#### Item Number: YFP-022

Product Name: 30" Wood Burning Firepit with Scroll Design

### **WARNINGS**:

- This firepit is intended for outdoor use only. <u>Do not</u> use on wooden decks.
- This firepit is intended to burn wood logs only. Do not burn coal, leaves, or other combustible materials in the pit.
- Not for use by children. Keep children and pets away from this firepit.
- The firepit is hot. Use with caution. Do not touch the hot firepit with bare hands.
- Never leave the burning firepit unattended, and always extinguish the fire completely before leaving the firepit.
- Do not use near flammable or combustible objects or materials.
- When the firepit is in use, the handle on the mesh screen can reach extreme temperatures that can cause serious injury to an unprotected hand. Use a poker or an appropriate heat resistant glove or pad when handling.
- DO NOT use this firepit as a cooking appliance. This firepit is not designed for grilling food.
- Check local fire regulations and municipal by-laws for safe use.
- Read all safety guidelines, warnings, instructions, and operating rules carefully before assembling and using this product.
- Some parts may contain sharp edges—especially as noted in the manual. Wear protective gloves if necessary.

No.	PARTS	Qty
А	Lift Handle	1
В	Screen	1
С	Wood grate	1
D	Fire Bowl	1
Е	Frame Ring	1
F	Decorative Frame	6
G	Base	1
Н	Fire Poker	1

## HARDWARE LIST

PARTS LIST

No.	Hardware	Qty
I	M6*12 Bolt	18
J	M6 Nut	6



Note: You will need a screwdriver to complete the assembly.

Step 1: Attach Lift Handle (A) to Screen (B); tighten with Nut M6 (J), as per Fig. 1



Step 2: Attach Frame Ring (E) to Decorative Frame (F) using Bolts (I). Do not fully tighten the bolts.



Step 3: Connect Base (G) to Decorative Frame (F) using Bolts (I) and Nut (J). Fully tighten all bolts.





Step 4: Place D, C, and B on the assembled frame. The firepit is now ready for use.



#### **ONE-YEAR LIMITED WARRANTY**

#### CUSTOMERS IN USA

For small parts please call 1-888-775-1330 for assistance. For damaged product, you may have to return to the retailer.

#### CUSTOMERS IN CANADA

Only return this product to the store if it was purchased within 90 days. If you have problems after 90 days of purchase, please CALL 1-888-775-1330. DATED PROOF OF PURCHASE REQUIRED FOR WARRANTY SERVICE.

AZ Patio Heater, LLC ("Vendor") warrants to the original retail purchaser of this heater to no other person, that if this heater is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one year from the date of purchase, all parts in such heater shall be free from defects in manufacturing and workmanship. Vendor may require reasonable

proof of your date of purchase from an authorized retailer or distributor. Therefore, you should retain your sales slip or invoice. This limited Warranty shall be limited to the repair or replacement

of parts, which prove defective under normal use and service and which the vendor shall determine

in its reasonable discretion upon examination to be defective. Before returning any parts, you should contact Vendors customer service department using the contact information listed below. If Vendor confirms, after examination a defect covered by this limited warranty in any returned part, and if Vendor approves the claim, Vendor will replace such defective part without charge. If you return defective parts, Transportation charges must be prepaid by you. Vendor will return replacement

parts to the original retail purchaser, Freight or postage prepaid.

The limited Warranty does not cover any failures or operating difficulties due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you

or third party. The failure to perform normal and routine maintenance on the product, shipping, damage, abnormal adjustment to the burner, damage or repairs related to insects, birds, or animals of any kind, and damage due to weather conditions as set out in this owner's manual. In addition,

the Limited Warranty does not cover damage to the finish such as scratches, dents, discoloration, rust or weather damage, after purchase. Please protect your investment.

The limited Warranty is in lieu of all other warranties offered by any retail company. Vendor disclaims all warranties for products that are purchased from sellers other than authorized retailers or distributors. AFTER THE PERIOD OF THE 1 YEAR WARRANTY, VENDOR DISCLAIMS ANY AND IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FURTHER, VENDOR SHALL HAVE NO LIABILITY WHATSOEVER TO PURCHASER OR ANY THIRD PARYY FOR ANY SPECIAL,

INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTAL DAMAGES. Vendor assumes no responsibility for any defects caused by third parties. This limited warranty gives the purchaser specific legal rights; a purchaser may have other rights depending upon where he or she lives. Some jurisdictions do not allow the exclusion or limitation of special, incidental or consequential damages, or limitations on how long a warranty lasts, so the above exclusion and limitations may not apply to you.

Vendor does not authorize any person or company to assume for it any other obligation or liability in connection with the sale, installation, use, removal, return, or replacement of its equipment, and no such representations are binding on vendor.

For warranty service, please contact warranty@azpatioheaters.com or call us toll free at 888-775-1330.

**Distributed by:** AZ Patio Heaters, LLC Toll Free Number **1-888-775-1330** Sales Service and Repair



www.azpatioheaters.com